




SPI Session Window

A Lifecycle Icons


















C Environment Icons







B Database Operation Icons


Document count:2 Connected User: joe

A. Lifecycle Icons		B. Database Operation Icons	
	Perform Check In operation on the selected Pro/ENGINEER object.		Perform SMARTTEAM Save operation on the Pro/ENGINEER object(s).
	Perform Check Out operation on the selected Pro/ENGINEER object.		Open the Profile Card of the selected Pro/ENGINEER object.
	Perform Undo Check Out operation on the selected Pro/ENGINEER object.		Replace the in-session model with the version from SPI Session.
	Perform Copy Out operation on the selected Pro/ENGINEER object.		Load Pro/ENGINEER Parameter values <u>from</u> SMARTTEAM Attributes.
C. Environment Icons			Load Pro/ENGINEER Parameter values <u>to</u> SMARTTEAM Attributes.
	Refresh SPI Session.		Set SPI Session Modification state to "Accept".
	Open SMARTTEAM File Explorer.		Set SPI Session Modification state to "Ignore".
	Open to modify SPI Session filter settings.		
	Open to modify SPI Session preferences.		

Troubleshooting

	Description	Action
 Already Exists Conflict	Appears when the same named object already exists in the SMARTEAM database	Perform a Copy OUT of the object from the SMARTEAM database to the folder location of the conflicting model.
File Status Column	File Status column compares the file copied to (or the file Checked OUT) from SMARTEAM to the version in the SMARTEAM vault. For instance, if a user performs a Pro/ENGINEER Save, the saved file will be more recent or “newer” than the file in the SMARTEAM vault. The File Status column will indicate that the in-session object is  Newer than the version in the SMARTEAM vault.	Perform a Save from SPI Session (Check out the object, if necessary).
ProE Status Column	The ProE Status column compares the in-session object to the saved version on the local hard drive (or working directory). For instance, if a user makes modifications to the model without saving, the in-session model is “modified” from the version saved in the working directory.	Perform a Save from the SPI Session.

Opening Renamed Objects [This option is applicable to users who migrated from Pro/INTRALINK]



Pro/ENGINEER objects in the Pro/INTRALINK database can be renamed using the Common Space Object Rename functionality. The file in the Pro/INTRALINK vault does not reference the newly renamed object until the parent of the renamed object (can be assembly, part, or drawing) is opened in Pro/ENGINEER and checked into the Pro/INTRALINK Database.

Click **SMARTEAM > Tools > Open Renamed** to open renamed Pro/INTRALINK objects in Pro/ENGINEER using SPI.